


Size guide



1 year warranty



200 kg**



95°



All slings should be tested and adjusted to the individual user to ensure optimal comfort and safety during transfers.

** Except for stand assist, Transfer stand assist & Standing transfer vest in combination with groin band: the safe working load is 159 kg.